

MOSAIC LAMP

THIS PRODUCT IS NOT A TOY. FOR DECORATIVE & INDOOR USE ONLY

I. OPERATION

1. Gently lift the unit from the packaging.
2. Plug the Mosaic Lamp plug into a working outlet.
3. Turn the "ON-OFF" dial from OFF to ON and the light will go on.

II. TROUBLE SHOOTING

Problem	Likely Cause	Solution
No light	No power	Make sure the unit plug is securely plugged into a working outlet.
	Faulty bulb	Replace with new E12 max 25W Bulb.

III. SAFETY WARNINGS AND INSTRUCTIONS

WARNING: THIS IS NOT A TOY!

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE. IF SERVICING IS NEEDED, SEND TO QUALIFIED SERVICE PERSONNEL.

PLEASE ADHERE TO THE FOLLOWING:

1. Read Instructions - All safety and operating instructions should be read before the appliance is operated. Please adhere to the instructions and warnings for your safety.
2. Water and Moisture - Do NOT put appliance near water of any kind: a bathtub, washbowl, kitchen sink, on a wet floor or near a swimming pool.
3. Heat - The appliance should be situated away from heat sources such as radiators, hairdryers, heat registers, stoves or other appliances that produce heat.
4. Power Sources - The appliance should be connected to a power supply only like the one which comes with the appliance.
5. Damage Requiring Service - Have a qualified service personnel service this appliance when:
 - A. The power-supply cord or plug has been damaged.
 - B. Objects have fallen or liquid has spilled into the appliance.
 - C. The appliance has been exposed to rain or moisture.
 - D. All troubleshooting techniques have been tried and the appliance will not work or has stopped working.
 - E. The appliance has been dropped or the enclosure damaged.

The following is only applicable to customers in the USA:

For more information about this product please call 1-800-467-9627. We will be happy to help you!

IV. NINETY-DAY LIMITED WARRANTY

Manufacturer warrants the original customer / purchaser of the **Mosaic Lamp** that it will be free from defects in material and workmanship for a period of ninety (90) days from date-of-purchase. Any liability under this warranty shall be limited to the repair or replacement of defective parts without charge if the item is returned with shipping charges prepaid together with proof of date-of-purchase, name and mailing address of the original consumers / purchasers. This warranty does not cover defects caused by damages in transit, abuse, accident, negligence or repairs made by others. This warranty gives the consumer / purchaser specific legal rights. This consumer / purchaser may also have other rights which vary from state to state.

Made in China

Made expressly for the Valerie Parr Hill Collection.

20121109 (v.1)